



HALCYON™ 7707 & 7708

TABLE

USER MANUAL

LET'S GET STARTED.



DESIGN MATTHEW WEATHERLY

BDi

BDIUSA.COM

Congratulations on the purchase of your Halcyon table from BDI. Your table has been designed to provide a lifetime of enjoyment. This manual will provide assembly instructions and other helpful information to ensure you get the most out of your product. Please save it for future reference.

Your Halcyon has been engineered for simple assembly. Please follow these directions carefully to prevent any damage.

Should you need further assistance, contact BDI at customerservice@bdiusa.com.

ENJOY!



HARDWARE AND COMPONENTS


Unpack and identify the parts listed below. The assembly workspace should be a non-marring surface, such as carpet. For missing hardware pieces, please contact BDI Customer Service at customerservice@bdiusa.com. For all other concerns, please contact your BDI retailer.

Do not use power tools for the assembly of this product.



Hex Wrench (T1)

QTY: 1




Screw M8 x 80 (H1)

QTY: 4




Split Lock Washer (H2)

QTY: 4



Flat Washer (H3)


QTY: 4



4 pre-assembled to table assembly; 4 in hardware pack

Screw M8 x 70 (H4)

QTY: 8



Pedestal (C1)

QTY: 1




Table Frame Assembly (C2)

QTY: 1




Table Top (C3)

QTY: 1



Large Drawer Liner
(C4)


QTY: 2





Small Drawer Liner
(C5)

QTY: 4

- With help from another person, place **Pedestal (C1)** in desired location.
- Before moving forward with assembly, check for levelness of the **Pedestal (C1)**.
- If **Pedestal (C1)** feels uneven or rocks when touched, have one person gently tip the **Pedestal (C1)** to one side while the other person turns the feet clockwise or counterclockwise by hand to adjust the height.
- Repeat adjustments until the pedestal is steady.




- With help from another person, unpack the table top assembly **UPSIDE DOWN**.
- Remove the **4 Screws (H4)** identified by a red ribbon from the **Table Frame Assembly (C2)**. The screws are located near the corners of the assembly.
- Set these aside in a safe spot. Discard the ribbon after removing the screws.
- Leave the **Table Frame Assembly (C2)** in the box until ready to place on **Pedestal (C1)**.




IMPORTANT: Avoid lifting the Table Frame Assembly (C2) by the drawers. Handle with lifting straps or frame.



- With help from another person, lift the **Table Frame Assembly (C2)** and carefully **flip** it over.
- Gently place it on top of the **Pedestal (C1)**.
- Cut and discard lifting strap from frame.
- When placed correctly, the 4 holes on the **Table Frame Assembly (C2)** will align with the 4 holes on the top of the **Pedestal (C1)**.



- Secure the **Table Frame Assembly (C2)** to the **Pedestal (C1)** using **4 Screws (H1)**, **4 Split Lock Washers (H2)**, and **4 Flat Washers (H3)** in the order shown.

NOTE: Insert all screws before fully tightening.


	HEX WRENCH – T1	QTY 1
	SCREW – H1	QTY 4
	SPLIT LOCK WASHER – H2	QTY 4
	FLAT WASHER – H3	QTY 4



STEP 5. PLACE AND ATTACH TABLE TOP


ASSEMBLY


- With help from another person, gently place the **Table Top (C3)** onto the **Table Frame Assembly (C2)**.
- Gently shift the **Table Top (C3)** until aligned with **Table Frame Assembly (C2)**.




- Secure the **Table Top (C3)** to the **Table Frame Assembly (C2)** using the **4 Screws (H4)** set aside earlier when unpacking the table top assembly, plus **4 Screws (H4)** from the hardware pack.

NOTE: Insert all screws before fully tightening.

	HEX WRENCH – T1	QTY 1
	SCREW – H4	QTY 8



- Insert **1 Large Drawer Liner (C4)** and **2 Small Drawer Liners (C5)** into the drawer.
- Repeat in the other drawer.



Your BDI furniture has been constructed with the finest materials, carefully manufactured, and designed to last a lifetime. Regular furniture care will prolong your enjoyment and keep it looking its best. Here are some general tips for taking care of BDI furniture. Your surfaces may vary.

GLASS

Glass surfaces are maintained using household glass cleaner and a paper towel or cloth.

SATIN-ETCHED GLASS

This uniquely smooth-to-the-touch glass surface can be regularly maintained using household glass cleaner and a paper towel or cloth.

A 'Magic Eraser' removes minor scratches or scuffs not eliminated using a paper towel or cloth. 'Magic Eraser' is a melamine foam product available at any grocery store or home improvement center. Dampen the entire glass surface and the Magic Eraser, then rub the whole surface in broad, even strokes using moderate pressure. Clean and dry the surface with a paper towel. Check for results and repeat as necessary. Any scratches or scuffing not eliminated by one of the above methods can often be addressed by 'refreshing' the glass. This process should not be required more than once per 6-12 months. See this brief video for the simple method: www.bdiusa.com/glass

WOOD

Wood surfaces should be cleaned with a slightly damp (not saturated) cloth or paper towel. Do not use glass cleaner on wood. If moisture remains, dry the surface with another cloth. If needed, a gentle, non-abrasive cleanser may be used, but wipe away all cleaner residue and dry the surface with a cloth.

BDI's wood finishes feature natural hardwood solids and veneers. Wood is a product of nature and—unlike man-made materials that can be manufactured to strict and consistent specifications—has natural imperfections that are part of its appeal and character. Every piece of wood differs from every other, even when coming from the very same tree. As such, grain, texture, and tone variation should be expected from one panel or piece of furniture to the next.

While BDI's stained wood finishes are stable in tone & appearance, all finishes are subject to some degree of discoloration with prolonged exposure to direct sunlight. Please avoid positioning your BDI furniture in any area with ample direct sunlight. To learn more about the features of natural wood, visit www.bdiusa.com/wood

METAL, PORCELAIN, SINTERED STONE, & PAINTED SURFACES

Surfaces should be cleaned with a slightly damp (not saturated) cloth or paper towel. If moisture remains, dry the surface with another cloth. If needed, a gentle, non-abrasive cleanser may be used, but be sure to wipe away all cleaner residue and dry the surface with a cloth.

WARRANTY

BDI warrants to the original purchaser that for the below-stated warranty term, BDI will replace any product, part, or component covered by this warranty that fails under normal use as a result of a defect in material or workmanship. The decision to replace a complete product versus the part or component in question will be at BDI's sole discretion.

Residential Use: BDI Furnishings carry warranty coverage for three (3) years from the date of product delivery, as shown on your sales receipt/documentation. Select chairs carry coverage for five (5) years from the date of product delivery.


Commercial Use: BDI Furnishings carry warranty coverage for one (1) year from the date of product delivery, as shown on your sales receipt/documentation. Select chairs carry coverage for five (5) years from the date of the product delivery, based on an 8-hour daily use pattern.

BDI reserves the right to refine or update its warranty from time to time. See the complete and latest warranty document at www.bdiusa.com/warranty.

PRODUCT REGISTRATION

Registering your new BDI product allows us to send you important product updates, service information, and helpful hints related to your BDI products.

Register today, and you will be **entered to win a free BINK table** from BDI: www.bdiusa.com/register



BDIUSA.COM

These distinctive product configurations are protected by US and international patents, trade dress, and/or copyright laws. Halcyon & BDI are trademarks of Becker Designed, Inc. All rights reserved. ©2026, BDI | V.08.17.2026

Made in Vietnam.